SV01A

Lenze
AC Tech

Operating Instructions



SMVector *- frequency inverter*

0.5 … 5 HP (0.37 kW… 4.0 kW)

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

Contents

1 Safety information 3

2 Technical data 5

2.1 Standards and application conditions 5
2.2 Ratings 6

3 Installation 8

3.1 Dimensions and mounting 8
3.2 Electrical installation 9
3.2.1 Power Connections 9
3.2.2 Fuses/cable cross-sections 11
3.2.3 Control terminals 12

4 Commissioning 13

4.1 Local Keypad & Display 13
4.2 Drive Displays and Modes of Operation 14
4.3 Parameter setting 14
4.4 Electronic programming module (EPM) 14
4.5 Parameter menu 15
4.5.1 Basic Setup Parameters 15
4.5.2 I/O Setup Parameters 18
4.5.3 Advanced Setup Parameters 22
4.5.4 PID Parameters 25
4.5.5 Vector Parameters 27
4.5.6 Network Parameters 28
4.5.7 Diagnostic Parameters 29

5 Troubleshooting and Diagnostics 31

5.1 Status/Warning Messages 31
5.2 Drive Configuration Messages 32
5.3 Fault Messages 33

Copyright © 2006 AC Technology Corporation

All rights reserved. No part of this manual may be reproduced or transmitted in any form without written permission from AC Technology Corporation. The information and technical data in this manual are subject to change without notice. AC Technology Corporation makes no warranty of any kind with respect to this material, including, but not limited to, the implied warranties of its merchantability and fitness for a given purpose. AC Technology Corporation assumes no responsibility for any errors that may appear in this manual.

All information given in this documentation has been carefully selected and tested for compliance with the hardware and software described. Nevertheless, discrepancies cannot be ruled out. We do not accept any responsibility nor liability for damages that may occur. Any necessary corrections will be implemented in subsequent editions.

This document printed in the United States

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

About these instructions

This documentation applies to the SMV frequency inverter, and contains important technical data and describes installation, operation, and commissioning.

These instructions are only valid for SMV frequency inverters with software rev 10 (see drive nameplate).

Please read the instructions before commissioning.



V0101

A Certifications
B Type
C Input Ratings
D Output Ratings
E Hardware Version
F Software Version

Scope of delivery	Important
• 1 SMV inverter (ESV...) with EPM installed (see Section 4.4) • 1 Operating Instructions	After receipt of the delivery, check immediately whether the items delivered match the accompanying papers. Lenze/AC Tech does not accept any liability for deficiencies claimed subsequently. **Claim** • visible transport damage immediately to the forwarder. • visible deficiencies / incompleteness immediately to your Lenze/AC Tech representative.

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

1 Safety information

General

Some parts of Lenze / AC Tech controllers can be electrically live and some surfaces can be hot.

Non-authorized removal of the required cover, inappropriate use, and incorrect installation or operation creates the risk of severe injury to personnel or damage to equipment.

All operations concerning transport, installation, and commissioning as well as maintenance must be carried out by qualified, skilled personnel who are familiar with the installation, assembly, commissioning, and operation of variable frequency drives and the application for which it is being used.

Installation

Ensure proper handling and avoid excessive mechanical stress. Do not bend any components and do not change any insulation distances during transport, handling, installation or maintenance.

Do not touch any electronic components or contacts. This drive contains electrostatically sensitive components, which can easily be damaged by inappropriate handling. Static control precautions must be adhered to during installation, testing, servicing and repairing of this drive and associated options. Component damage may result if proper procedures are not followed.

This drive has been tested by Underwriters Laboratory (UL) and is an approved component in compliance with UL508 Safety Standard.

This drive must be installed and configured in accordance with both national and international standards. Local codes and regulations take precedence over recommendations provided in this and other Lenze / AC Tech documentation.

The SMVector drive is considered a component for integration into a machine or process. It is neither a machine nor a device ready for use in accordance with European directives (reference machinery directive and electromagnetic compatibility directive). It is the responsibility of the end user to ensure that the machine meets the applicable standards.

Electrical connection

When working on live drive controllers, applicable national safety regulations must be observed.

The electrical installation must be carried out according to the appropriate regulations (e.g. cable cross-sections, fuses, protective earth [PE] connection). While this document does make recommendations in regards to these items, national and local codes must be adhered to.

The documentation contains information about installation in compliance with EMC (shielding, grounding, filters and cables). These notes must also be observed for CE-marked controllers.

The manufacturer of the system or machine is responsible for compliance with the required limit values demanded by EMC legislation.

Application

The drive must not be used as a safety device for machines where there is a risk of personal injury or material damage. Emergency Stops, over-speed protection, acceleration and deceleration limits, etc must be made by other devices to ensure operation under all conditions.

The drive does feature many protection devices which are aimed at protecting the drive and the driven equipment by generating a fault and shutting the drive and motor down by removing power. Mains power variances can also result in shutdown of the drive. When the fault condition disappears or is cleared, the drive can be configured to automatically restart, it is the responsibility of the user and/or OEM and/or integrator to ensure that the drive is configured for safe operation.

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

Safety information

All safety information given in these Operating Instructions have the same layout:

Signal Word! (characterizes the severity of the danger)

Note (describes the danger and informs on how to proceed)

Icon		Signal Words	
	Warning of hazardous electrical voltage	**DANGER!**	Warns of **impending danger**. Consequences if disregarded: Death or severe injuries.
	Warning of a general danger	**WARNING!**	Warns of **potential, very hazardous situations**. Consequences if disregarded: Death or severe injuries.
	Warning of damage to equipment	**STOP!**	Warns of **potential damage to material and equipment**. Consequences if disregarded: Damage to the controller/drive or its environment.
	Information	**Note**	Designates a general, useful note. If you observe it, handling the controller/drive system is made easier.

Note for UL approved system with integrated controllers: UL warnings are notes which apply to UL systems. The documentation contains special information about UL.

Warnings!

- Suitable for use on a circuit capable of delivering not more than 200,000 rms symmetrical amperes, at the maximum voltage rating marked on the drive.
- Use minimum 75 °C copper wire only.
- Shall be installed in a pollution degree 2 macro-environment.

Operation

Systems including controllers must be equipped with additional monitoring and protection devices according to the corresponding standards (e.g. technical equipment, regulations for prevention of accidents, etc.). The controller may be adapted to your application as described in this documentation.

DANGER!

- After the controller has been disconnected from the supply voltage, live components and power connection must not be touched immediately, since capacitors could be charged. Please observe the corresponding notes on the controller.
- Please close all protective covers and doors prior to and during operation.
- Do not cycle input power to the controller more than once every two minutes.

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

2 Technical data

2.1 Standards and application conditions

Conformity	CE	Low Voltage Directive (73/23/EEC)
Approvals	UL 508C	Underwriters Laboratories - Power Conversion Equipment
Input voltage phase imbalance	≤ 2%	
Humidity	≤ 95% non-condensing	
Temperature range	Transport	-25 … +70°C
	Storage	-20 … +70°C
	Operation	-10 … +55°C (with 2.5%/°C current derating above +40°C)
Installation height	0 … 4000m a.m.s.l. (with 5%/1000 m current derating above 1000m a.m.s.l.)	
Vibration resistance	acceleration resistant up to 1.0g	
⚠ **Earth leakage current**	> 3.5 mA to PE	
Enclosure	IP 21 / IP 31 / NEMA 1	
Protection measures against	short circuit, earth fault, phase loss, over voltage, under voltage, motor stalling, over temperature, motor overload	

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

2.2 Ratings

120VAC Doubler / 240VAC Models

Type	Power [Hp/kW]	Mains			Output Current		Watts Loss
		Voltage(1)	I_{in} (120V)	I_{in} (240V)	I_n	$CLim_{max}$ (2)	
ESV251N01SXB	0.33 / 0.25	**120 V Single-phase (1/N/PE)** (90 … 132 V) **OR** **240 V Single-phase (2/PE)** (170 … 264 V)	6.8	3.4	1.7	200	24
ESV371N01SXB	0.5 / 0.37		9.2	4.6	2.4	200	32
ESV751N01SXB	1 / 0.75		16.6	8.3	4.2	200	52

240VAC Models

Type	Power [Hp/kW]	Mains			Output Current		Watts Loss
		Voltage(1)	I_{in} 1~ (2/PE)	I_{in} 3~ (3/PE)	I_n	$CLim_{max}$ (2)	
ESV251N02SXB	0.33 / 0.25	**240 V Single Phase (2/PE)**	3.4	-	1.7	200	20
ESV371N02YXB	0.5 / 0.37	**240 V Single-phase (2/PE)** **OR** **240 V Three-phase (3/PE)** (170 … 264 V)	5.1	2.9	2.4	200	27
ESV751N02YXB	1 / 0.75		8.8	5.0	4.2	200	41
ESV112N02YXB	1.5 / 1.1		12.0	6.9	6.0	200	64
ESV152N02YXB	2 / 1.5		13.3	8.1	7.0	200	75
ESV222N02YXB	3 / 2.2		17.1	10.8	9.6	200	103
ESV112N02TXB	1.5 / 1.1	**240 V Three-phase (3/PE)** (170 V … 264 V)	-	6.9	6.0	200	64
ESV152N02TXB	2 / 1.5		-	8.1	7.0	200	75
ESV222N02TXB	3 / 2.2		-	10.8	9.6	200	103
ESV402N02TXB	5 / 4.0		-	18.6	16.5	200	154

(1) Frequency Range: 48 Hz … 62 Hz
(2) Current Limit (CLim) is a percentage of the output current, I_n. $CLim_{max}$ is the maximum setting for P171.

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

480VAC Models

Type	Power [Hp/kW]	Mains			Output Current				Watts Loss
		Voltage(1)	I_{in}		I_n		$CLim_{max}$ (2)		
			400V	480V	400V	480V	400V	480V	
ESV371N04TXB	0.5 / 0.37	**400 V Three-phase (3/PE)** (340 … 440 V) **OR** **480 V Three-phase (3/PE)** (340 … 528 V)	1.7	1.5	1.3	1.1	175	200	23
ESV751N04TXB	1 / 0.75		2.9	2.5	2.4	2.1	175	200	37
ESV112N04TXB	1.5 / 1.1		4.2	3.6	3.5	3.0	175	200	48
ESV152N04TXB	2 / 1.5		4.7	4.1	4.0	3.5	175	200	57
ESV222N04TXB	3 / 2.2		6.1	5.4	5.5	4.8	175	200	87
ESV402N04TXB	5 / 4.0		10.6	9.3	9.4	8.2	175	200	128

600VAC Models

Type	Power [Hp/kW]	Mains	Output Current			Watts Loss
		Voltage(1)	I_{in}	I_n	$CLim_{max}$ (2)	
ESV751N06TXB	1 / 0.75	**600 V Three-phase (3/PE)** (425 … 660 V)	2.0	1.7	200	**37**
ESV152N06TXB	2 / 1.5		3.2	2.7	200	51
ESV222N06TXB	3 / 2.2		4.4	3.9	200	68
ESV402N06TXB	5 / 4.0		6.8	6.1	200	101

(1) Frequency Range: 48 Hz … 62 Hz

(2) Current Limit (CLim) is a percentage of the output current, I_n. $CLim_{max}$ is the maximum setting for P171.
For 480VAC models, the $CLim_{max}$ value in the 480V column of the table is used when P107 is set to 1.
The $CLim_{max}$ value in the 400V column is used when P107 is set to 0.

STOP!

Drive Derating

The SMVector drive is designed to operate at the Nominal Output Current (I_n) shown in the Ratings tables for most standard applications and industrial environments. The drive output current or operating temperature may need to be limited as described below:

- For installations above 1000m a.m.s.l., derate I_n by 5% per 1000m, do not exceed 4000m a.m.s.l.
- Operation above 40°C, derate I_n by 2.5% per °C, do not exceed 55°C.
- Carrier Frequency (P166):
  - If P166=2 (8 kHz), derate I_n to 92% of drive rating or do not exceed 33°C ambient
  - If P166=3 (10 kHz), derate I_n to 84% of drive rating or do not exceed 27°C ambient

For combinations of the above, please consult Lenze / AC Tech applications support for proper derating.

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

3 Installation

3.1 Dimensions and mounting



V0102

Type	a in (mm)	a1 in (mm)	b in (mm)	b1 in (mm)	b2 in (mm)	c in (mm)	s1 in (mm)	s2 in (mm)	m lb (kg)
ESV251N01SXB ESV251N02SXB ESV371N01SXB ESV371N02YXB ESV371N04TXB ESV751N01SXB ESV751N02YXB ESV751N04TXB ESV751N06TXB	3.90 (99)	3.10 (79)	7.50 (190)	7.00 (178)	.25 (6)	4.35 (110)	0.6 (15)	2.0 (50)	2.0 (0.9)
ESV112N02TXB ESV112N02YXB ESV112N04TXB ESV152N02TXB ESV152N02YXB ESV152N04TXB ESV152N06TXB ESV222N02TXB ESV222N02YXB ESV222N04TXB ESV222N06TXB	3.90 (99)	3.10 (79)	7.50 (190)	7.00 (178)	.25 (6)	5.45 (138)	0.6 (15)	2.0 (50)	2.8 (1.3)
ESV402N02TXB ESV402N04TXB ESV402N06TXB	3.90 (99)	3.10 (79)	7.50 (190)	7.00 (178)	.25 (6)	5.80 (147)	0.6 (15)	2.0 (50)	3.2 (1.5)

Warning!

Drives must not be installed where subjected to adverse environmental conditions such as: combustible, oily, or hazardous vapors or dust; excessive moisture; excessive vibration or excessive temperatures. Contact Lenze / AC Tech for more information.

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net



3.2 Electrical installation

3.2.1 Power Connections

DANGER!

Hazard of electrical shock! Circuit potentials are up to 600 VAC above earth ground. Capacitors retain charge after power is removed. Disconnect power and wait at least three minutes before servicing the drive.

STOP!

- Verify mains voltage before connecting to drive.
- Do not connect mains power to the output terminals (U,V,W)! Severe damage to the drive will result.
- Do not cycle mains power more than once every two minutes. Damage to the drive will result.

3.2.1.1 Mains connection to 120VAC Single-Phase Supply



3.2.1.2 Mains connection to 240VAC Single-Phase Supply



3.2.1.3 Mains connection to Three-Phase Supply

ESV…N02Y…
ESV…N02T…
ESV…N04T…
ESV…N06T…
(3/PE AC)



3.2.1.4 Motor Connection





Mains and Motor Terminations

12 lb-in (1.3 Nm)

0.25 in (6mm)

WARNING!

Leakage current may exceed 3.5 mA AC. Minimum size of the protective earth conductor shall comply with local safety regulations for high leakage current equipment.

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net



3.2.2 Fuses/cable cross-sections

Note

Observe local regulations.
Local codes may supersede these recommendations

Type		Recommendations				
		Fuse	Miniature circuit breaker(1)	Fuse(2) or Breaker(3) (N. America)	Input Power Wiring (L1, L2, L3, PE)	
					[mm²]	[AWG]
120V 1~ (1/N/PE)	ESV251N01SXB	M10 A	C10 A	10 A	1.5	14
	ESV371N01SXB	M16 A	C16 A	15 A	2.5	14
	ESV751N01SXB	M25 A	C25 A	25 A	4	10
240V 1~ (2/PE)	ESV251N01SXB, ESV251N02SXB, ESV371N01SXB, ESV371N02YXB	M10 A	C10 A	10 A	1.5	14
	ESV751N01SXB, ESV751N02YXB	M16 A	C16 A	15 A	2.5	14
	ESV112N02YXB	M20 A	C20 A	20 A	2.5	12
	ESV152N02YXB	M25 A	C25 A	25 A	2.5	12
	ESV222N02YXB	M30 A	C30A	30 A	4	10
240V 3~ (3/PE)	ESV371N02YXB, ESV751N02YXB	M10 A	C10 A	10 A	1.5	14
	ESV112N02YXB, ESV152N02YXB, ESV112N02TXB, ESV152N02TXB	M12 A	C12 A	12 A	1.5	14
	ESV222N02YXB, ESV222N02TXB	M20 A	C20 A	20 A	2.5	12
	ESV402N02TXB	M30 A	C30 A	30 A	4.0	10
400V 3~(3/PE)	ESV371N04TXB...ESV222N04TXB	M10 A	C10 A	10 A	1.5	14
	ESV402N04TXB	M16 A	C16 A	20 A	2.5	14
480V 3~(3/PE)	ESV371N04TXB...ESV222N04TXB	M10 A	C10 A	10 A	1.5	14
	ESV402N04TXB	M16 A	C16 A	15 A	2.5	14
600V 3~(3/PE)	ESV751N06TXB...ESV222N06TXB	M10 A	C10 A	10 A	1.5	14
	ESV402N06TXB	M12 A	C12 A	12 A	1.5	14

(1) Installations with high fault current due to large supply mains may require a type D circuit breaker.
(2) UL Class CC or T fast-acting current-limiting type fuses, 200,000 AIC, preferred. Bussman KTK-R, JJN or JJS or equivalent.
(3) Thermomagnetic type breakers preferred.

Observe the following when using Ground Fault Circuit Interrupters (GFCIs):

- Installation of GFCI only between supplying mains and controller.
- The GFCI can be activated by:
  - capacitive leakage currents between the cable screens during operation (especially with long, screened motor cables)
  - connecting several controllers to the mains at the same time
  - RFI filters

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

3.2.3 Control terminals

Terminal	Data for control connections	
1	Digital Input: Start/Stop	input resistance = 4.3kΩ
2	Analog Common	
5	Analog Input: 0...10 VDC	input resistance: >50 kΩ
6	Internal DC supply for speed pot	+10 VDC, max. 10 mA
25	Analog Input: 4...20 mA	input resistance: 250Ω
4	Digital Reference/Common	+15 VDC / 0 VDC, depending on assertion level
11	Internal DC supply for external devices	+12 VDC, max. 50 mA
13A	Digital Input: Configurable with P121	input resistance = 4.3kΩ
13B	Digital Input: Configurable with P122	
13C	Digital Input: Configurable with P123	
14	Digital Output: Configurable with P142	DC 24 V / 50 mA; NPN
30	Analog Output: Configurable with P150…P155	0…10 VDC, max. 20 mA
16	Relay output: Configurable with P140	AC 250 V / 3 A DC 24 V / 2 A … 240 V / 0.22 A, non-inductive
17		



Assertion level of digital inputs

The digital inputs can be configured for active-high or active-low by setting the Assertion Level Switch (ALsw) and P120. If wiring to the drive inputs with dry contacts or with PNP solid state switches, set the switch and P120 to “High” (+). If using NPN devices for inputs, set both to “Low” (-). Active-high (+) is the default setting.

HIGH = +12 … +30 V
LOW = 0 … +3 V

Note

An **F.AL** fault will occur if the Assertion Level switch (ALsw) position does not match the parameter P120 setting and P100 or any of the digital inputs (P121...P123) is set to a value other than 0.

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

4 Commissioning

4.1 Local Keypad & Display



V0105

START BUTTON:
In Local Mode (P100 = 0, 4), this button will start the drive.

STOP BUTTON: stops the drive, regardless of which mode the drive is in.

WARNING!
When JOG is active, the STOP button will not stop the drive!

ROTATION:
In Local Mode (P100 = 0, 4), this selects the motor rotation direction:
- The LED for the present rotation direction (FWD or REV) will be on
- Press R/F; the LED for the opposite rotation direction will blink
- Press M within 4 seconds to confirm the change
- The blinking direction LED will turn on, and the other LED will turn off

When rotation direction is changed while the drive is running, the commanded direction LED will blink until the drive is controlling the motor in the selected direction.

MODE:
Used to enter/exit the Parameter Menu when programming the drive and to enter a changed parameter value.

UP AND DOWN BUTTONS:
Used for programming and can also be used as a reference for speed, PID setpoint, or torque setpoint. When the ▲ and ▼ buttons are the active reference, the middle LED on the left side of the display will be on.

INDICATING LEDs

FWD/REV LEDs: Indicate the present rotation direction. See ROTATION above.

AUTO LED: Indicates that the drive has been put into Auto mode from one of the TB13 inputs (P121…P123 set to 1…7). Also indicates that PID mode is active (if enabled).

RUN LED: Indicates that the drive is running

▲▼ LED: Indicates that the ▲▼ are the active reference.

Note
If the keypad is selected as the auto reference (P121…P123 is 6) and the corresponding TB-13 input is closed, the AUTO LED and ▲▼ LEDs will both be on

4.2 Drive Displays and Modes of Operation

Speed Mode Display
In the standard mode of operation, the drive frequency output is set directly by the selected reference (keypad, analog reference, etc.). In this mode, the drive display will show the drive's output frequency.

PID Mode Display
When the PID mode is enabled and active, the normal run display shows the actual PID setpoint. When PID mode is not active, the display returns to showing the drive's output frequency.

Torque Mode Display
When the SMVector is operating in Vector Torque mode, the normal run display shows the drive's output frequency.

4.3 Parameter setting



4.4 Electronic programming module (EPM)

The EPM contains the SMVector's operational memory. Parameter settings are stored in the EPM and setting changes are made to the "User settings" in the EPM.

An optional EPM Programmer (model EEPM1RA) is available that allows:

- An EPM to be copied directly to another EPM.
- An EPM to be copied to the memory of the EPM Programmer.
- Stored files can be modified in the EPM Programmer.
- Stored files can be copied to another EPM.

As the EPM Programmer is battery operated, parameter settings can be copied to an EPM and inserted into a drive without power being applied to the drive. This means that the drive will be fully operational with the new settings on the next application of power.

Additionally, when the SMV's parameter settings are burned into an EPM with the EPM Programmer, the settings are saved in two distinct locations; the "User settings" and the "OEM default settings". While the User settings can be modified in the drive, the OEM settings cannot. Thus, the drive can be reset not only to the "factory" drive default settings (shown in this manual), but can be set to the Original Machine settings as programmed by the OEM.

While the EPM can be removed for copying or to use in another drive, it must be installed for the SMVector drive to operate (a missing EPM will trigger an **F.F I** fault).

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

4.5 Parameter menu

4.5.1 Basic Setup Parameters

Code		Possible Settings		IMPORTANT
No.	Name	Default	Selection	
P100	Start Control Source	0	0 Local Keypad	Use RUN button on front of drive to start
			1 Terminal Strip	Use start/stop circuit wired into the terminal strip. See Section 3.2.3
			2 Remote Keypad Only	Use RUN button on optional Remote Keypad to start
			3 Network Only	• Start command must come from network (Modbus, CANopen, etc) • Requires optional communication module (refer to instructions included with module). • Must also set one of the TB-13 inputs to 9 (Network Enable); see P121...P123
			4 Terminal Strip or Local Keypad	Allows start control to be switched between terminal strip and local keypad using one of the TB-13 inputs. See note below.
			5 Terminal Strip or Remote Keypad	Allows start control to be switched between terminal strip and optional remote keypad using one of the TB-13 inputs. See note below.
		WARNING! P100 = 0 disables TB-1 as a STOP input! STOP circuitry may be disabled if parameters are reset back to defaults (see P199)		
		Note • P100 = 4, 5: To switch between control sources, one of the TB-13 inputs (P121...P123) must be set to 08 (Control Select); TB-13x OPEN (or not configured): Terminal strip control TB-13x CLOSED: Local (P100 = 4) or Remote (P100 = 5) keypad • P100 = 0, 1, 4: Network can take control if P121...P123 = 9 and the corresponding TB-13x input is CLOSED. • The STOP button on the front of the drive is always active except in JOG mode. • An F.AL fault will occur if the Assertion Level switch (ALsw) position does not match the P120 setting and P100 is set to a value other than 0.		
P101	Standard Reference Source	0	0 Keypad (Local or Remote)	Selects the default speed or torque reference when no Auto Reference is selected using the TB-13 inputs
			1 0-10 VDC	
			2 4-20 mA	
			3 Preset #1	
			4 Preset #2	
			5 Preset #3	
			6 Network	

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

Code		Possible Settings				IMPORTANT
No.	Name	Default	Selection			
P102	Minimum Frequency	0.0	0.0	{Hz}	P103	• P102, P103 are active for all speed references • When using an analog speed reference, also see P160, P161
P103	Maximum Frequency	60.0	7.5	{Hz}	500	
			Note To set P103 above 120 Hz: • Scroll up to 120 Hz; display shows H iFr (flashing). • Release ▲ button and wait one second • Press ▲ button again to continue increasing P103			
	WARNING! Consult motor/machine manufacturer before operating above rated frequency. Overspeeding the motor/machine may cause damage to equipment and injury to personnel!					
P104	Acceleration Time 1	20.0	0.0	{s}	3600	• P104 = time of frequency change from 0 Hz to P167 (base frequency) • P105 = time of frequency change from P167 to 0 Hz • For S-ramp accel/decel, adjust P106
P105	Deceleration Time 1	20.0	0.0	{s}	3600	
	Example: if P103 = 120 Hz, P104 = 20.0 s and P167 (base frequency) = 60 Hz; rate of frequency change from 0 Hz to 120 Hz = 40.0 s					
P106	S-Ramp Integration Time	0.0	0.0	{s}	50.0	• P106 = 0.0: Linear accel/decel ramp • P106 > 0.0: Adjusts S-ramp curve for smoother ramp
P107(1)	Line Voltage Selection	1*	0 Low (120, 200, 400, 480VAC) 1 High (120, 240, 480, 600VAC)			* The default setting is 1 for all drives except when using "reset 50" (Parameter P199, selection 4) with 480V models. In this case, the default setting is 0.
P108	Motor Overload	100	30	{%}	100	P108 = (motor current rating / SMV output rating) x 100 **Example:** motor = 3 amps; SMV = 4 amps; P108 = 75%
			Note Do not set above the rated motor current as listed on the motor dataplate. The motor thermal overload function of the SMV is UL approved as a motor protection device. If line power is cycled, the motor thermal state is reset to cold state. Cycling power after an overload fault could result in significantly reducing the motor life.			
P109	Motor Overload Type	0	0 Speed Compensation 1 No Speed Compensation			 V0108

(1) Any changes to this parameter will not take effect until the drive is stopped

Code		Possible Settings		IMPORTANT
No.	Name	Default	Selection	
P110	Start Method	0	0 Normal	
			1 Start on Power-up	Drive will automatically start when power is applied.
			2 Start with DC Brake	When start command is applied, drive will apply DC braking according to P174, P175 prior to starting the motor
			3 Auto Restart	Drive will automatically restart after faults, or when power is applied.
			4 Auto Restart with DC Brake	Combines settings 2 and 3
			5 Flying Start/Restart #1	• Drive will automatically restart after faults, or when power is applied. • After 3 failed attempts, drive will Auto Restart with DC brake. • P110 = 5: Performs speed search, starting at Max Frequency (P103) • P110 = 6: Performs speed search, starting at the last output frequency prior to faulting or power loss • If P111 = 0, a flying START is performed when a start command is applied.
			6 Flying Start/Restart #2	
		Note • P110 = 0, 2: Start command must be applied at least 2 seconds after power-up; F.UF fault will occur if start command is applied too soon. • P110 = 1, 3…6: For automatic start/restart, the start source must be the terminal strip and the start command must be present. • P110 = 2, 4…6: If P175=999.9, dc braking will be applied for 15s. • P110 = 3…6: Drive will attempt 5 restarts; if all restart attempts fail, drive displays LC (fault lockout) and requires manual reset. • P110 = 5, 6: If drive cannot catch the spinning motor, drive will trip into F.rF fault.		
		WARNING! Automatic starting/restarting may cause damage to equipment and/or injury to personnel! Automatic starting/restarting should only be used on equipment that is inaccessible to personnel.		
P111	Stop Method	0	0 Coast	Drive's output will shut off immediately upon a stop command, allowing the motor to coast to a stop
			1 Coast with DC Brake	The drive's output will shut off and then the DC Brake will activate (see P174, P175)
			2 Ramp	The drive will ramp the motor to a stop according to P105 or P126.
			3 Ramp with DC Brake	The drive will ramp the motor to 0 Hz and then the DC Brake will activate (see P174, P175)
P112	Rotation	0	0 Forward Only	If PID mode is enabled, reverse direction is disabled (except for Jog).
			1 Forward and Reverse	

4.5.2 I/O Setup Parameters

Code		Possible Settings		IMPORTANT
No.	Name	Default	Selection	
P120	Assertion Level	2	1 Low 2 High	P120 and the Assertion Level switch must both match the desired assertion level unless P100, P121…P123 are all set to 0. Otherwise an F.AL fault will occur.
P121 P122 P123	TB-13A Input Function TB-13B Input Function TB-13C Input Function	0	0 None	Disables input
			1 AUTO Reference: 0-10 VDC	For frequency mode, see P160...P161, For PID mode, see P204…P205, For vector torque mode, see P330
			2 AUTO Reference: 4-20 mA	
			3 AUTO Reference: Preset	For frequency mode see P131...P137, For PID mode, see P231…P233, For torque mode see, P331…P333
			4 AUTO Reference: MOP Up	• Normally open: Close input to increase or decrease speed, PID setpoint or torque setpoint. • MOP Up is not active while in STOP
			5 AUTO Reference: MOP Down	
			6 AUTO Reference: Keypad	
			7 AUTO Reference: Network	
			8 Control Select	Use when P100 = 4, 5 to switch between terminal strip control and local or remote keypad control.
			9 Network Enable	Required to start the drive through the network.
			10 Reverse Rotation	Open = Forward Closed = Reverse
			11 Start Forward	See note for typical circuit
			12 Start Reverse	
			13 Run Forward	See note for typical circuit
			14 Run Reverse	
			15 Jog Forward	Jog Forward speed = P134
			16 Jog Reverse	Jog Reverse speed = P135 ⚠ Active even if P112 = 0
			17 Accel/Decel #2	See P125, P126
			18 DC Brake	See P174; close input to override P175
			19 Auxiliary Ramp to Stop	Normally closed: Opening input will ramp drive to STOP according to P127, even if P111 is set to Coast (0 or 1).
			20 Clear Fault	Close to reset fault
			21 External Fault F.EF	Normally closed circuit; open to trip
			22 Inverse External Fault F.EF	Normally open circuit; close to trip

⚠ **WARNING!**
Jog overrides all STOP commands! To stop the drive while in Jog mode, the Jog input must be deactivated or a fault condition induced.

Code		Possible Settings				IMPORTANT
No.	Name	Default	Selection			

Note
- When input is activated, settings 1...7 override P101
- When TB-13A...TB-13C are configured for Auto References other than MOP, TB-13C overrides TB-13B, and TB-13B overrides TB-13A. Any other Auto Reference will have priority over MOP.
- Settings 10...14 are only valid in Terminal Strip mode (P100 = 1, 4, 5)
- If Start/Run/Jog Forward and Start/Run/Jog Reverse are both activated, drive will STOP
- If Jog input is activated while the drive is running, the drive will enter Jog mode; when Jog input is deactivated, drive will STOP
- An **F.AL** fault will occur if the Assertion Level switch (ALsw) position does not match the P120 setting and any of the digital inputs (P121...P123) are set to a value other than 0.
- An **F.IL** fault will occur under the following conditions:
  - TB-13A...TB-13C settings are duplicated (each setting, except 0 and 3, can only be used once)
  - One input is set to "MOP Up" and another is not set to "MOP Down", or vice-versa.
  - One input is set to 10 and another input is set to 11…14.
  - One input is set to 11 or 12 and another input is set for 13 or 14.
- Typical control circuits are shown below:
  - If any input is set to 10, 12 or 14, P112 must be set to 1 for Reverse action to function.

Run / Stop with Direction
P121 = 10



Start Forward / Start Reverse
P121 = 11, P122 = 12



Run Forward / Run Reverse
P121 = 13, P122 = 14



P125	Acceleration Time 2	20.0	0.0	{s}	3600	• Selected using TB-13A...TB-13C (P121...P123 = 17) • For S-ramp accel/decel, adjust P106
P126	Deceleration Time 2	20.0	0.0	{s}	3600	
P127	Deceleration Time for Auxiliary Ramp to Stop	20.0	0.0	{s}	3600	• Selected using TB-13A...TB-13C (P121...P123 = 19). • For S-ramp accel/decel, adjust P106 • Once executed, this ramp time has priority over P105 and P126.
P131	Preset Speed #1	0.0	0.0	{Hz}	500	
P132	Preset Speed #2	0.0	0.0	{Hz}	500	
P133	Preset Speed #3	0.0	0.0	{Hz}	500	
P134	Preset Speed #4	0.0	0.0	{Hz}	500	
P135	Preset Speed #5	0.0	0.0	{Hz}	500	
P136	Preset Speed #6	0.0	0.0	{Hz}	500	
P137	Preset Speed #7	0.0	0.0	{Hz}	500	

PRESET SPEED	13A	13B	13C
1	X	--	--
2	--	X	--
3	--	--	X
4	X	X	--
5	X	--	X
6	--	X	X
7	X	X	X

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

Code		Possible Settings		IMPORTANT
No.	Name	Default	Selection	
P 140	Relay Output TB-16, 17	0	0 None	Disables the output
			1 Run	Energizes when the drive is running
			2 Reverse	Energizes when Reverse rotation is active
			3 Fault	De-energizes when the drive trips, or power is removed
			4 Inverse Fault	Energizes when the drive trips
			5 Fault Lockout	P110 = 3...6: De-energizes if all restart attempts fail
			6 At Speed	Energizes when output frequency = commanded frequency
			7 Above Preset Speed #6	Energizes when output frequency > P136
			8 Current Limit	Energizes when motor current = P171
			9 Follower Loss (4-20 mA)	Energizes when 4-20 mA signal falls below 2 mA
			10 Loss of Load	Energizes when motor load drops below P145; see also P146
			11 Local Keypad Control Active	Energizes when the selected source is active for start control
			12 Terminal Strip Control Active	
			13 Remote Keypad Control Active	
			14 Network Control Active	
			15 Standard Reference Active	Energizes when P101 reference is active
			16 Auto Reference Active	Energizes when Auto Reference is activated using TB-13 input; see P121...P123
			17 Sleep Mode Active	See P240...P242
			18 PID Feedback < Min. Alarm	Energizes when PID feedback signal < P214
			19 Inverse PID Feedback < Min. Alarm	De-energizes when PID feedback signal < P214
			20 PID Feedback > Max Alarm	Energizes when PID feedback signal > P215
			21 Inverse PID Feedback > Max Alarm	De-energizes when PID feedback signal > P215
			22 PID Feedback within Min/Max Alarm range	Energizes when PID feedback signal is within the Min/Max Alarm range; see P214, P215
			23 PID Feedback outside Min/Max Alarm range	Energizes when PID feedback signal is outside the Min/Max Alarm range; see P214, P215

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

Code		Possible Settings				IMPORTANT
No.	Name	Default	Selection			
P142	TB-14 Output	0	0...23 (same as P140)			
			24 Dynamic Braking			For use with Dynamic Braking option
P145	Loss of Load Threshold	0	0	{%}	200	P140, P142 = 10: Output will energize if motor load falls below P145 value longer than P146 time
P146	Loss of Load Delay	0.0	0.0	{s}	240.0	
P150	TB-30 Output	0	0 None			2-10 VDC signal can be converted to 4-20 mA with a total circuit impedance of 500 Ω
			1 0-10 VDC Output Frequency			
			2 2-10 VDC Output Frequency			
			3 0-10 VDC Load			
			4 2-10 VDC Load			
			5 0-10 VDC Torque			
			6 2-10 VDC Torque			
			7 0-10 VDC Power (kW)			
			8 2-10 VDC Power (kW)			
P152	TB-30 Scaling: Frequency	60.0	3.0	{Hz}	2000	If P150 = 1 or 2, sets the frequency at which output equals 10 VDC
P153	TB-30 Scaling: Load	200	10	{%}	500	If P150 = 3 or 4, sets the Load (as a percent of drive current rating) at which output equals 10 VDC.
P154	TB-30 Scaling: Torque	100	10	{%}	1000	If P150 = 5 or 6, sets the Torque (as a percent of motor rated torque) at which output equals 10 VDC
P155	TB-30 Scaling: Power (kW)	1.0	0.1	{kW}	200.0	If P150 = 7 or 8, sets the power at which output equals 10 VDC

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

4.5.3 Advanced Setup Parameters

Code		Possible Settings				IMPORTANT
No.	Name	Default	Selection			
P160	Speed at Minimum Signal	0.0	-999.0	{Hz}	1000	 V0111
P161	Speed at Maximum Signal	60.0	-999.0	{Hz}	1000	
		Note • P160 sets the output frequency at 0% analog input • P161 sets the output frequency at 100% analog input • P160 or P161 < 0.0 Hz: For scaling purposes only; does not indicate opposite direction! • P160 > P161: Drive will react inversely to analog input signal				
P162	Analog Input Filter	0.01	0.00	{s}	10.00	Adjusts the filter on the analog inputs (TB-5 and TB-25) to reduce the effect of signal noise
P163	TB-25 Loss Action	0	0 No Action 1 Fault F.FaL 2 Go to Preset when TB-25 is: Speed reference: P137 PID feedback source: P137 PID setpoint reference: P233 Torque reference: P333			• Selects the reaction to a loss of the 4-20 mA signal at TB-25. • Signal is considered lost if it falls below 2 mA • Digital outputs can also indicate a loss of 4-20 mA signal; see P140, P142
P166	Carrier Frequency	1	0 4 kHz 1 6 kHz 2 8 kHz 3 10 kHz			• As carrier frequency is increased, motor noise is decreased • Observe derating in Section 2.2 • Automatic shift to 4 kHz at 120% load
P167(1)	Base Frequency	60.0	10.0	{Hz}	1500	 V0112
P168	Fixed Boost		0.0	{%}	30.0	
		Note • P167 = rated motor frequency for standard applications • P168 default setting depends on drive rating				
P169	Accel Boost	0.0	0.0	{%}	20.0	Accel Boost is only active during acceleration

(1) Any changes to this parameter will not take effect until the drive is stopped

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

Code		Possible Settings				IMPORTANT
No.	Name	Default	Selection			
P170	Slip Compensation	0.0	0.0	{%}	10.0	Increase P170 until the motor speed no longer changes between no load and full load conditions.
P171 (1)	Current Limit	200	30	{%}	$CLim_{max}$	• When the limit is reached, the drive displays CL, and either the acceleration time increases or the output frequency decreases. • Digital outputs can also indicate when the limit is reached; see P140, P142. • Refer to section 2.2 for $CLim_{max}$
P174	DC Brake Voltage	0.0	0.0	{%}	30.0	Setting is a percent of the nominal DC bus voltage.
P175	DC Brake Time	0.0	0.0	{s}	999.9	
		Note CONFIRM MOTOR SUITABILITY FOR USE WITH DC BRAKING DC Brake voltage (P174) is applied for the time specified by P175 with the following exceptions: • If P111=1, 3 and P175=999.9 the brake voltage will be applied continuously until a run or fault condition occurs. • If P110=2, 4…6 and P175=999.9, brake voltage will be applied for 15s • If P121…P123=18 and the corresponding TB-13 input is CLOSED, brake voltage will be applied until the TB-13 input is OPENED or a fault condition occurs.				
P178	Display Frequency Multiplier	0.00	0.00		650.00	• Allows frequency display to be scaled • P178 = 0.00: Scaling disabled • P178 > 0.00: Display = Actual Frequency X P178
		Example: If P178 = 29.17 and actual frequency = 60 Hz, Drive displays 1750 (rpm)				
P179	Run Screen Display	0	0	{Parameter Number}	599	• 0 = Normal Run Screen, this display depends on mode of operation. See Section 4.2. • Other selections choose a diagnostic parameter to display (P501…P599).
P181	Skip frequency 1	0.0	0.0	{Hz}	500	• Drive will not run in the defined skip range; used to skip over frequencies that cause mechanical vibration • P181 and P182 define the start of the skip ranges • P184 > 0 defines the bandwidth of both ranges.
P182	Skip frequency 2	0.0	0.0	{Hz}	500	
P184	Skip frequency bandwidth	0.0	0.0	{Hz}	10.0	
		Note Bandwidth (Hz) = f_s (Hz) + P184 (Hz) f_s = P181 or P182 **Example:** P181 = 18 Hz and P184 = 4 Hz; skip range is from 18 to 22 Hz				

(1) Any changes to this parameter will not take effect until the drive is stopped

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

Commissioning

Code		Possible Settings		IMPORTANT
No.	Name	Default	Selection	
P 194	Password	225	0000 9999	• Must enter password to access parameters • P194 = 0000: Disables password
P 197	Clear Fault History	0	0 No Action	
			1 Clear Fault History	
P 199	Program Selection		0 Operate from User settings	
			1 Operate from OEM settings	See Notes 1, 2 and 3
			2 Reset to OEM default settings	See Note 1
			3 Reset to 60 Hz default settings	• See Note 4 • Parameters are reset to the defaults listed in this manual. • For P199=4, the following exceptions apply: - P103, P152, P161, P167 = 50.0 Hz - P304 = 50 Hz; - P305 = 1450 RPM - P107 = 0 (480 V drives only)
			4 Reset to 50 Hz default settings	
			5 Translate	See Note 5

WARNING!
Modification of P199 can affect drive functionality! STOP and EXTERNAL FAULT circuitry may be disabled! Check P100 and P121...P123

Note 1
If the EPM does not contain valid OEM settings, a flashing GF will be displayed when P199 is set to 1 or 2.

Note 2
When P199 is set to 1, the drive operates from the OEM settings stored in the EPM Module and no other parameters can be changed (CE will be displayed if attempted).

Note 3
Auto Calibration is not possible when operating from OEM Settings.

Note 4
Reset 60 and Reset 50 will set the Assertion Level (P120) to "2" (High). P120 may need to be reset for the digital input devices being used. An F.AL fault may occur if P120 and the Assertion switch are not set identically.

Note 5
If an EPM that contains data from a previous compatible software version is installed:
- The drive will operate according to the previous data, but parameters cannot be changed (cE will be displayed if attempted)
- To update the EPM to the current software version, set P199 = 5. The parameters can now be changed but the EPM is incompatible with previous software revisions.

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

4.5.4 PID Parameters

Code		Possible Settings				IMPORTANT
No.	Name	Default	Selection			
P200	PID Mode	0	0 Disabled 1 Normal-acting 2 Reverse-acting			• Normal-acting: As feedback increases, motor speed decreases • Reverse-acting: As feedback increases, motor speed increases • PID mode is disabled in Vector Torque mode (P300 = 5)
		Note To activate PID mode, one of the TB-13 inputs (P121...P123) must be used to select the Auto Reference that matches the desired PID setpoint reference. If the selected PID setpoint reference uses the same analog signal as the PID feedback (P201), an **F.IL** fault will occur. **Example:** The desired PID setpoint reference is the keypad (▲ and ▼). Set TB-13x = 6 (Auto Reference: Keypad): • TB-13x = closed: PID mode is active • TB-13x = open: PID mode is disabled and the drive speed will be controlled by the reference selected in P101.			
P201	PID Feedback Source	0	0 4-20 mA (TB-25) 1 0-10 VDC (TB-5)			Must be set to match the PID feedback signal
P202	PID Decimal Point	1	0 PID Display = XXXX 1 PID Display = XXX.X 2 PID Display = XX.XX 3 PID Display = X.XXX 4 PID Display = .XXXX			Applies to P204, P205, P214, P215, P231...P233, P242, P522, P523
P204	Feedback at Minimum Signal	0.0	-999.0		5500.0	Set to match the range of the feedback signal being used **Example:** Feedback signal is 0 - 300 PSI; P204 = 0.0, P205 = 300.0
P205	Feedback at Maximum Signal	100.0	-999.0		5500.0	
P207	Proportional Gain	5.0	0.0	{%}	100.0	Used to tune the PID loop: • Increase P207 until system becomes unstable, then decrease P207 by 10-15% • Next, increase P208 until feedback matches setpoint • If required, increase P209 to compensate for sudden changes in feedback
P208	Integral Gain	0.0	0.0	{s}	20.0	
P209	Derivative Gain	0.0	0.0	{s}	20.0	
		Note • Derivative Gain is very sensitive to noise on the feedback signal and must be used with care • Derivative Gain is not normally required in pump and fan applications				
P210	PID Setpoint Ramp	20.0	0.0	{s}	100.0	• time of setpoint change from P204 to P205 or vice versa. • Used to smooth the transition from one PID setpoint to another, such as when using the Preset PID Setpoints (P231...P233)

Code		Possible Settings				IMPORTANT
No.	Name	Default	Selection			
P214	Minimum Alarm	0.0	P204		P205	Use with P140, P142 = 18...23
P215	Maximum Alarm	0.0	P204		P205	
P231	Preset PID Setpoint #1	0.0	P204		P205	TB-13A activated; P121 = 3 and P200 = 1 or 2
P232	Preset PID Setpoint #2	0.0	P204		P205	TB-13B activated; P122 = 3 and P200 = 1 or 2
P233	Preset PID Setpoint #3	0.0	P204		P205	TB-13C activated; P123 = 3 and P200 = 1 or 2
P240	Sleep Threshold	0.0	0.0	{Hz}	500.0	• If drive speed < P240 for longer than P241, output frequency = 0.0 Hz; drive display = SLP • P240 = 0.0: Sleep mode is disabled. • P200 = 0…2: Drive will start again when speed command is above P240 • P242 > 0.0: Drive will restart when the PID feedback differs from the setpoint by more than the value of P242 ***or*** when the PID loop requires a speed above P240.
P241	Sleep Delay	30.0	0.0	{s}	300.0	
P242	Sleep Bandwidth	0.0	0.0		B_{max} Where: B_{max} = |(P205 - P204)|	

4.5.5 Vector Parameters

Code		Possible Settings				IMPORTANT
No.	Name	Default	Selection			
P300(1)	Drive Mode	0	0 Constant V/Hz			Constant torque V/Hz control for general applications
			1 Variable V/Hz			Variable torque V/Hz control for centrifugal fan and pump applications
			2 Enhanced Constant V/Hz			For single or multiple motor applications that require better performance than settings 0 or 1, but cannot use Vector mode, due to: • Missing required motor data • Vector mode causing unstable motor operation
			3 Enhanced Variable V/Hz			
			4 Vector Speed			For single-motor applications requiring higher starting torque and speed regulation
			5 Vector Torque			For single-motor applications requiring torque control independent of speed
		Note To configure the drive for either Vector mode or Enhanced V/Hz mode: • P300 = 4, 5: - Set P302...P306 according to motor nameplate - Set P399 = 1 - Make sure motor is cold (20° - 25° C) and apply a Start command - Display will indicate CAL for about 40 seconds - Once the calibration is complete, the display will indicate StoP; apply another Start command to actually start the motor - If an attempt is made to start the drive in Vector or Enhanced V/Hz mode before performing the Motor Calibration, the drive will display F.n Id and will not operate • P300 = 2, 3: Same as above but only need to set P302…P304			
P302(1)	Motor Rated Voltage		0	{V}	600	• Default setting = SMV rating • Set to motor nameplate data
P303(1)	Motor Rated Current		0.0	{A}	500.0	
P304(1)	Motor Rated Frequency	60	0	{Hz}	1000	Set to motor nameplate data
P305(1)	Motor Rated Speed	1750	300	{RPM}	65000	
P306(1)	Motor Cosine Phi	0.80	0.40		0.99	
		Note If motor cosine phi is not known, use one of the following formulas: cos phi = motor Watts / (motor efficiency X P302 X P303 X 1.732) cos phi = cos [$\sin^{-1}$ (magnetizing current / motor current)]				

(1) Any changes to this parameter will not take effect until the drive is stopped

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

Code		Possible Settings				IMPORTANT
No.	Name	Default	Selection			
P310[1]	Motor Stator Resistance	0.00	0.00	{Ω}	64.00	• Will be automatically programmed by P399 • Changing these settings can adversely affect performance. Contact factory technical support prior to changing
P311[1]	Motor Stator Inductance	0.0	0.0	{mH}	2000	
P330	Torque Limit	100	0	{%}	400	When P300 = 5, sets the maximum output torque.
P331	Preset Torque Setpoint #1	100	0	{%}	400	TB-13A activated; P121 = 3 and P300 = 5
P332	Preset Torque Setpoint #2	100	0	{%}	400	TB-13B activated; P122 = 3 and P300 = 5
P333	Preset Torque Setpoint #3	100	0	{%}	400	TB-13C activated; P123 = 3 and P300 = 5
P340[1]	Current Loop P Gain	0.25	0.00		16.0	Changing these settings can adversely affect performance. Contact factory technical support prior to changing.
P341[1]	Current Loop I Gain	65	12	{ms}	9990	
P342[1]	Speed Loop Adjustment	0.0	0.0	{%}	20.0	
P399	Motor Auto-calibration	0	0 Calibration Not Done			• If P300 = 2...5, motor calibration must be performed, but motor data must be programmed first • An alternating CAL / Err will occur if: - motor calibration is attempted with P300 = 0 or 1 - motor calibration is attempted before programming motor data
			1 Calibration Enabled			
			2 Calibration Complete			

(1) Any changes to this parameter will not take effect until the drive is stopped

4.5.6 Network Parameters

Code		Possible Settings		IMPORTANT
No.	Name	Default	Selection	
P400	Network Protocol		0 Not Active	Read-only based upon the communication module installed.
			1 Remote Keypad	
			2 Modbus RTU	
			3 CANopen	
			4 DeviceNet	
			5 Ethernet	
			6 Profibus	

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

4.5.7 Diagnostic Parameters

Code		Display Range (READ ONLY)			IMPORTANT
No.	Name				
P500	Fault History				• Displays the last 8 faults • Format: n.xxx where: n = 1..8; 1 is the newest fault xxx = fault message (without the **F.**) • see Section 5.3
P501	Software version				Format: x.yz
P502	Drive ID				A flashing display indicates that the Drive ID stored in the EPM does not match the SMV drive model it is plugged into.
P503	Internal Code				Alternating Display: xxx-; -yy
P505	DC Bus Voltage	0	{VDC}	1500	
P506	Motor Voltage	0	{VAC}	1000	
P507	Load	0	{%}	255	Motor load as % of drive's output current rating. See section 2.2.
P508	Motor Current	0.0	{A}	1000	Actual motor current
P509	Torque	0	{%}	500	Torque as % of motor rated torque (vector mode only)
P510	kW	0.00	{kW}	650.0	
P511	kWh	0.0	{kWh}	9999999	Alternating display: xxx-; yyyy when value exceeds 9999
P512	Heatsink Temp	0	{°C}	150	Heatsink temperature
P520	0-10 VDC Input	0.0	{VDC}	10.0	Actual value of signal at TB-5
P521	4-20 mA Input	0.0	{mA}	20.0	Actual value of signal at TB-25
P522	TB-5 Feedback	P204		P205	TB-5 signal value scaled to PID feedback units
P523	TB-25 Feedback	P204		P205	TB-25 signal value scaled to PID feedback units
P525	Analog Output	0	{VDC}	10.0	See P150…P155
P527	Actual Output Frequency	0	{Hz}	500.0	
P528	Network Speed Command	0	{Hz}	500.0	Command speed if (Auto: Network) is selected as the speed source
P530	Terminal and Protection Status				Indicates terminal status using segments of the LED display. (See section 4.5.7.1)
P531	Keypad Status				Indicates keypad button status using segments of the LED display. (See section 4.5.7.2)
P540	Total Run Time	0	{h}	9999999	Alternating display: xxx-; yyyy when value exceeds 9999
P541	Total Power On Time	0	{h}	9999999	

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

4.5.7.1 Terminal and Protection Status Display

Parameter P530 allows monitoring of the control terminal points and common drive conditions:
An illuminated LED segment indicates:

- the protective circuit is active (LED 1)
- the Logic Assertion Switch is set to High (+)
- input terminal is asserted (LED 2)
- output terminal is energized (LED 4)
- the Charge Relay is not a terminal, this segment will be illuminated when the Charge Relay is energized (LED 4).



4.5.7.2 Keypad Status Display

Parameter P531 allows monitoring of the keypad pushbuttons:
An illuminated LED segment indicates when the button is depressed.



5 Troubleshooting and Diagnostics

5.1 Status/Warning Messages

Status / Warning		Cause	Remedy
br	DC-injection brake active	DC-injection brake activated • activation of digital input (P121...P123 = 18) • automatically (P110 = 2, 4...6) • automatically (P111 = 1, 3)	Deactivate DC-injection brake • deactivate digital input • automatically after P175 time has expired
bF	Drive ID warning	The Drive ID (P502) stored on the EPM does not match this SMV drive model.	• Verify motor data (P302…P306) and perform Auto Calibration. • Set drive mode (P300) to 0 or 1 • Reset the drive (P199 to 3 or 4) and reprogram.
CAL	Motor Auto-calibration is being performed	See P300, P399	
cE	An EPM that contains valid data from a previous software version has been installed	An attempt was made to change parameter settings	Parameter settings can only be changed after the EPM data is converted to the current version (P199 = 5)
CL	Current Limit (P171) reached	Motor overload	• Increase P171 • Verify drive/motor are proper size for application
dEC	Decel Override	The drive has stopped decelerating to avoid tripping into **HF** fault, due to excessive motor regen (2 sec max).	If drive trips into **HF** fault: • Increase P105, P126 • Install Dynamic Braking option
Err	Error	Invalid data was entered, or an invalid command was attempted	
FCL	Fast Current Limit	Overload	Verify drive/motor are proper size for application
FSt	Flying Restart Attempt after Fault	P110 = 5,6	
GE	OEM Settings Operation warning	An attempt was made to change parameter settings while the drive is operating in OEM Settings mode (P199 = 1)	In OEM Settings mode, making changes to parameters is not permitted
GF	OEM Defaults data warning	An attempt was made to use (or reset to) the OEM default settings (P199 = 1 or 2) using an EPM without valid OEM data.	Install an EPM containing valid OEM Defaults data
LC	Fault Lockout	The drive attempted 5 restarts after a fault but all attempts were unsuccessful (P110 = 3...6)	• Drive requires manual reset • Check Fault History (P500) and correct fault condition
PdEC	PID Deceleration Status	PID setpoint has finished its ramp but the drive is still decelerating to a stop.	

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

Status / Warning		Cause	Remedy
PId	PID Mode Active	Drive has been put into PID Mode. See P200.	
SLP	Sleep Mode is active	See P240...P242	
SP	Start Pending	The drive has tripped into a fault and will automatically restart (P110 = 3...6)	To disable Auto-Restart, set P110 = 0...2
SPd	PID Mode disabled.	Drive has been taken out of PID Mode. See P200.	
StoP	Output frequency = 0 Hz (outputs U, V, W inhibited)	Stop has been commanded from the keypad, terminal strip, or network	Apply Start command (Start Control source depends on P100)

5.2 Drive Configuration Messages

When the Mode button is pressed and held, the drive's display will provide a 4-digit code that indicates how the drive is configured. If the drive is in a Stop state when this is done, the display will also indicate which control source commanded the drive to Stop
(the two displays will alternate every second).

Configuration Display			
Format = x.y.zz	**x = Control Source:** L = Local Keypad t = Terminal Strip r = Remote Keypad n = Network	**y = Mode:** S = Speed mode P = PID mode t = Vector Torque mode	**zz = Reference:** CP = Keypad ▲ ▼ EU = 0-10 VDC (TB-5) E I = 4-20 mA (TB-25) JG = Jog nt = Network OP = MOP P 1...P7 = Preset 1...7
	Example: • L.S.CP = Local Keypad Start control, Speed mode, Keypad speed reference • t.P.EU = Terminal Strip Start control, PID mode, 0-10 VDC setpoint reference • n.t.P2 = Network Start control, Vector Torque mode, Preset Torque #2 reference		
Stop Source Display			
Format = x.StP	L.StP = Stop command came from Local Keypad t.StP = Stop command came from Terminal Strip r.StP = Stop command came from Remote Keypad n.StP = Stop command came from Network		

5.3 Fault Messages

The messages below show how they will appear on the display when the drive trips. When looking at the Fault History (P500), the **F.** will not appear in the fault message.

Fault		Cause	Remedy (1)
F.AF	High Temperature fault	Drive is too hot inside	• Reduce drive load • Improve cooling
F.AL	Assertion Level fault	• Assertion Level switch is changed during operation • P120 is changed during operation • P100 or P121...P123 are set to a value other than 0 and P120 does not match the Assertion Level Switch.	• Make sure the Assertion Level switch and P120 are both set for the type of input devices being used, prior to setting P100 or P121...P123. See 3.2.3 and P120.
F.bF	Personality fault	Drive Hardware	• Cycle Power • Power down and install EPM with valid data • Reset the drive back to defaults (P199 = 3, 4) and then re-program • If problem persists, contact factory technical support
F.CF	Control fault	An EPM has been installed that is either blank or corrupted	
F.cF	Incompatible EPM fault	An EPM has been installed that contains data from an incompatible parameter version	
F.dbF	Dynamic Braking fault	Dynamic braking resistors are overheating	• Increase active decel time (P105, P126, P127). • Check mains voltage and P107
F.EF	External fault	• P121…P123 = 21 and that digital input has been opened. • P121…P123 = 22 and that digital input has been closed.	• Correct the external fault condition • Make sure digital input is set properly for NC or NO circuit
F.F1	EPM fault	EPM missing or defective	Power down and replace EPM
F.F2 ... F.F12	Internal faults		Contact factory technical support
F.Fnr	Invalid message received	• A network message was received while in Remote Keypad mode • A remote keypad message was received while in Network mode	Only the remote keypad or the network can be connected at one time; see P100
F.FoL	Loss of 4-20 mA signal fault	4-20 mA signal (at TB-25) is below 2 mA (P163 = 1)	Check signal/signal wire
F.OF	OEM Defaults data fault	Drive is powered up with P199 =1 and OEM settings in the EPM are not valid.	Install an EPM containing valid OEM Defaults data or change P199 to 0.
F.HF	High DC Bus Voltage fault	Mains voltage is too high	Check mains voltage and P107
		Decel time is too short, or too much regen from motor	Increase active decel time (P105, P126, P127) or install Dynamic Braking option

(1) The drive can only be restarted if the error message has been reset

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net

Fault		Cause	Remedy [1]
F. IL	Digital Input Configuration fault (P121...P123)	More than one digital input set for the same function	Each setting can only be used once (except settings 0 and 3)
		Only one digital input configured for MOP function (Up, Down)	One input must be set to MOP Up, another must be set to MOP Down
		PID mode is entered with setpoint reference and feedback source set to the same analog signal	Change PID setpoint reference (P121…P123) or feedback source (P201).
		One of the digital inputs (P121… P123) is set to 10 and another is set to 11…14.	Reconfigure digital inputs
		One of the digital inputs (P121… P123) is set to 11 or 12 and another is set to 13 or 14.	
		PID enabled in Vector Torque mode (P200 = 1 or 2 and P300 = 5)	PID cannot be used in Vector Torque mode
F.UF	Remote keypad fault	Remote keypad disconnected	Check remote keypad connections
F.LF	Low DC Bus Voltage fault	Mains voltage too low	Check mains voltage
F.n Id	No Motor ID fault	An attempt was made to start the drive in Vector or Enhanced V/Hz mode prior to performing the Motor Auto-calibration	See P300…P399 for Drive Mode setup and calibration.
F.nEF	Network fault	Network watchdog timer timed out	Check network connections
F.OF	Output fault: Transistor fault	Output short circuit	Check motor/motor cable
		Acceleration time too short	Increase P104, P125
		Severe motor overload, due to: • Mechanical problem • Drive/motor too small for application	• Check machine / system • Verify drive/motor are proper size for application
		Boost values too high	Decrease P168, P169
		Excessive capacitive charging current of the motor cable	Use shorter motor cables with lower charging current
		Failed output transistor	Contact factory technical support
F.OF I	Output fault: Ground fault	Grounded motor phase	Check motor and motor cable
		Excessive capacitive charging current of the motor cable	Use shorter motor cables with lower charging current
F.PF	Motor Overload fault	Excessive motor load for too long	• Verify proper setting of P108 • Verify drive and motor are proper size for application
F.rF	Flying Restart fault	Controller was unable to synchronize with the motor during restart attempt; (P110 = 5 or 6)	Check motor / load
F.SF	Single-Phase fault	A mains phase has been lost	Check mains voltage
F.UF	Start fault	Start command was present when power was applied (P110 = 0 or 2).	Must wait at least 2 seconds after power-up to apply Start command

(1) The drive can only be restarted if the error message has been reset

Phone: 800.894.0412 - Fax: 208.368.0415 - www.ctiautomation.net - e.mail: info@ctiautomation.net